


DOWNLOADING SELECTIVE CLUSTER INFORMATION FROM SMARTDIRECTOR (running software version 4.x)

Steps to follow

This is what you will see


Step 1.

Login to the smartdirector of the cluster and click on **Admin Tools** from the Applications menu.



Step 2.

Under the **Cluster Data** section, enter in the default **admin** account credentials and click on **Select & Download Data** button as shown.



The screenshot shows the 'Cluster Data' section of the smartdirector wtec interface. It contains several options for downloading data and technical support information. The 'Select & Download Data' button is highlighted with a red arrow.

Cluster Data

Download Site Inventory Data
[Engines](#) [Fixtures](#)

Download Technical Support Information
[Basic](#) [Complete](#)

Write comments to Log Files
 Comments: [Submit](#)

Download information across Cluster - from Director and Engines
 Username: Password:

[Select & Download Data](#) [Download All](#)

Step 3.

You will see a page with all the appliances that are part of the cluster (including the smartdirector).

Select the specific checkboxes for the information that you would like to gather from any of the appliances.

*Unless requested by wtec's Technical Support team, in most cases, **Statistics will not be needed**, so it is OK to not include it.*

After all the selections have been made, click on the **Download Selected Data** button below on the page.

- This action will download a file called...

ClusterDataFor_<smartDirector name>(<smartdirector IP>)_XXXXXXXXXXXXX.tgz

It is a compressed file.

***Note:** This can be a fairly large file, so your patience is requested with this download.*

Step 4.

Send this compressed file to the requester for review.

Select engines to download data from:

- **SD01(192.168.2.61)**
 - ☒ Support Data
 - ☐ Statistics
 - ☒ Fixture List
 - ☒ Basic Support Info
- **SE03(192.168.2.68)**
 - ☒ Support Data
 - ☐ Statistics
 - ☒ Basic Support Info
- **SE01(192.168.2.67)**
 - ☒ Support Data
 - ☐ Statistics
 - ☒ Basic Support Info

Download Selected Data